


300配件说明书




列表/Table:001

300

01-1

序号 DET	编 号 PART NUMBER	DESCRIPTION	零 件 描 述	数量 QTY
1	C85KN10-20	Stopping cylinder	止动气缸	1
2	300 010020	Cylinder threading assembly	气缸勾线租件	1
3	GB/T 70.1 M3X10	Screw M3X10	内六角螺丝	2
4	GB/T 61 M12	Nut M12	螺母	1
5	GB/T 61 M4	Nut M4	螺母	3
6	GB/T 77 M3X5	Screw M3X5	平端紧定螺钉	2
7	300 010070	Looper base	线钩座	1
8	300 010080	Looper	线钩	1
9	300 010090	Fixed plate	固定板	1
10	300 010100	Cylinder fixed bracket	气缸固定支架	1
11	300 010110	Cylinder positioning pin	气缸定位销	1
12	C85N10-10	Cylinder	气缸	1
13	GB/T 896 ϕ 4	Spit washer ϕ 4	开口挡圈	1
14	300 010140	Adjustable stop couar	调节挡圈	1
15	300 010150	Cylinder connecting head	气缸连接头	1
16	300 010160	Cutter fixed bracker	切刀固定支架	1
17	GB/T 70.1 M3X10	Screw M3X10	内六角螺丝	1
18	300 010180	Copper ring	铜圈1	1
19	300 010190	Pin	销钉	1
20	300 010200	Fixed pin	固定销钉	1
21	300 010210	Copper ring	铜圈2	1
22	300 010220	Cutting	切刀	1
23	GB/T 896 ϕ 4	Ring ϕ 4	开口挡圈	1
24	GB/T 70.1 M3X10	Screw M3X10	内六角螺丝	2
25	300 010250	Fixed plate	固定片	1
26	300 010260	Transparent stop plate	透明挡片	1
27	300 010270	Connecting bracker head and cutter	机头切割刀连接支架	1
28	GB/T 77 M3X5	Screw M3X5	平端紧定螺钉	2
29	GB/T 70.1 M4X20	Screw M4X20	内六角螺丝	1
30	300 010300	Prossure foot guiding rod	压脚导杆	1
31	300 010310	Needle bar	针杆	1
32	300 010320	Needle file	针座	1
33	GB/T 77 M3X5	Screw M3X5	平端紧定螺钉	2
34	300 010340	Needle board	针板	1
35	GB/T 68 M8X5	Screw M8X5	一字沉头螺钉	2
36	300 010360	Needle	机针	2
37	300 010370	Feed dog	送步牙	2
38	GB/T 72 M3X6	Screw M3X6	一字螺钉	2
39	300 010390	Thread stand	穿线架	2
40	GB/T 97 ϕ 3	Washer ϕ 3	垫片	3
41	GB/T 70.2 M3X6	Screw M3X6	圆头内六角螺丝	3
42	300 010420	Thread stand	线架	1
43	300 010430	Skim pack	吸油器	1
44	300 010440	Pressuto feet	压脚	1
45	GB/T 70.2 M4X8	Screw M4X8	圆头内六角螺丝	1
46	300 010460	Needle pretection board	护针板	1
47	300 010470	Needle pretection board washer	护针板垫片	1
48	GB/T 72 M8X13	Screw M8X13	一字螺钉	1
49	300 010490	Air tap	气嘴	1
50	300 010500	Top pin ϕ 6X24.6	顶销	1
51	EPL4-M5	Air connection	气接头	4
52	GB/T 72 M5X10	Screw M5X10	一字螺丝	1
53	GB/T 70.1 M3X10	Screw M3X10	内六角螺丝	1

链式珠边机



列表/Table:002

300

02-1

序号 DET	编 号 PART NUMBER	DESCRIPTION	零 件 描 述	数量 QTY
1	GB/T 70.2 M3X6	Screw M3X6	圆头内六角螺丝	1
2	300 020020	Pressing plats	压板	1
3	300 020030	Fork needle plate	叉针片	1
4	300 020040	Fork needle fixed base	叉针固定座	1
5	300 020050	Pin	销钉	1
6	300 020060	Guiding sleeve	导套	1
7	300 020070	Fixing base	固定座	1
8	300 020080	Connecting block	连接块	1
9	GB/T 70.1 M4X10	Screw M4X10	内六角螺丝	1
10	300 020100	Setup fixed plate	安装固定板	1
11	GB/T 70.1 M4X15	Screw M4X15	内六角螺丝	2
12	300 020120	Occentric wheel	偏心传动轮	1
13	300 020130	Connecting rod	连杆	1
14	HK0808	Needke Bearing	滚针轴承	1
15	300 020150	Pressing plate	压板	1
16	GB/T 70.1 M3X15	Screw M3X15	内六角螺丝	1
17	300 020170	Thread hooking plate	勾线片	1
18	GB/T 70.2 M3X4	Screw M3X4	圆头内六角螺丝	2
19	GB/T 77 M4X4	Screw M4X4	平端紧定螺钉	4
20	300 020200	Pixed shrink ring	固定紧圈	2
21	GB/T 70.1 M4X16	Screw M4X16	内六角螺丝	1
22	300 020220	Thread hooking plate base	勾线片座	1
23	300 020230	Gearing connection	传动连接件	1
24	GB/T 61 M3	Nut M3	螺母	1
25	GB/T 97 ϕ 1	Washer ϕ 1	垫片	1
26	300 020260	Guiding bar ϕ 8 L=74	导杆	1
27	300 020270	Copper ring	铜圈	1
28	300 020280	Iron sleeve	铁套	1
29	GB/T 97 ϕ 2	Washer ϕ 2	垫片	2
30	GB/T 70.1 M5X20	Screw M5X20	内六角螺丝	1
31	GB/T 70.1 M5X12	Screw M5X12	内六角螺丝	1
32	GB/T 70.1 M5X8	Screw M5X8	内六角螺丝	1
33	300 020330	Positioning fixator	定位固定器	1
34	GB/T 70.1 M3X10	Screw M3X10	内六角螺丝	1
35	SI3TIK	Knuckle bearing M3	关节轴承	3
36	GB/T 61 M3	Nut M3	螺母	2
37	300 020370	Connecting rod	连杆	1
38	300 020380	Swinging block	摆动块	1
39	HK0810	Needle bearing	滚针轴承	2
40	300 020400	Fixed guiding bar	固定导杆	1
41	300 020410	Main shaft	主轴	1
42	300 020420	Eccentric wheel	偏心轮	1
43	300 020430	Eccentric wheel connecting block	偏心轮连接块	1
44	GB/T 77 M4X4	Screw M4X4	平端紧定螺钉	2
45	300 020450	Connecting screw	连接螺丝	1
46	GB/T 70.1 M3X10	Screw M3X10	内六角螺丝	1
47	300 020470	Slider	滑块	1
48	GB/T 70.1 M3X15	Screw M3X15	内六角螺丝	1
49	GB/T 97 ϕ 8	Washer ϕ 8X ϕ 13X1	垫片	1
50	GB/T 97 ϕ 8	Washer ϕ 8X ϕ 11X0.5	垫片	1



链式珠边机

